



SIRONA MEASUREMENT AND DOSING INSTRUCTIONS

On first use, or a new complete fill up of your tub:

Use the provided hose filter to fill up your tub with water. Remove any unwanted particles. Then:

1. Test the water with testing strip. Consult the dosage tables; balance water with Spa Up or Spa Down as needed.
2. Add 3 TBSP* of Oxidizer. Wait 15 minutes before use.
3. Add 1 TBSP Sirona Simply Sanitizer.

** The measuring spoon provided is 1 Tablespoon (TBSP).*

Weekly maintenance:

Test once a week, or if the water is cloudy.

1. Test and adjust PH or Alkalinity using Spa Up or Down using the **dosage tables** on the following page.
2. Add 3 TBSP of Oxidizer
3. If Sirona Simply Sanitizer is less than 30ppm, add ½ TBSP.

Dosage Tables

3 teaspoons (tsp) equal 1 Tablespoon (1 TBSP).

PH reading:

7.1 or below	7.2 - 7.8	7.9 - 8.1	8.2 - 8.5
1 tsp Spa Up	Ideal range No action needed	½ tsp Spa Down	1 tsp Spa Down

Alkalinity reading:

0 - 20	21 - 40	41 - 60	61 - 80	80 - 120	120 - 140	140 - 160	160 - 180	180 - 200
2 TBSP Spa Up	1 TBSP Spa Up	2 tsp Spa Up	½ tsp Spa Up	Ideal range No action needed	½ tsp Spa Down	2 tsp Spa Down	1 TBSP Spa Down	2 TBSP Spa Down

Sanitizer reading:

0-15	30-80
½ TBSP	Ideal range No action needed